

Coastal Countertops  
33 Sarah Greenfield Way  
Farmington, NH 03835  
603-755-2268



## GRANITE /QUARTZ COUNTERTOP PROCESS PREPARATION Day of Install Reminders

- Cover living areas or doors to adjacent living areas to contain dust. Countertop installation is a construction process and some residual dust can be expected.
- It is recommended to remove all contents from any sink base cabinets prior to installation.
- Ensure that your installation does not conflict with other work being done in the same area.
- Be sure the path to the installation area is clear.
- If you, or your contractor are removing your old countertop, please be sure it is done prior to your install date.
- All plumbing must be disconnected prior to the install date. Any Faucets should be on site in the proper room.
- Ensure all cabinets are level. This will prevent the countertops from cracking and breaking under unsupported stress.
- If the stove is a slide-in-range, the stove must be pulled out of place and out of the way for install.
- Care will be exercised during installation; however, scrapes, scratches or dings to wall surfaces, and existing backsplash may occur. These items are considered incidental damage and will be the customer's responsibility to repair.
- Some cutouts may be partially or completely created in your home.
- Due to the unevenness of finished walls, gaps between the countertop and backsplash may not be consistent.
- If you elect for Coastal Countertops to remove and haul away your old countertops, this is a demolition process. Some damage to walls, existing backsplash and/or cabinets may occur. This is the customer's responsibility to repair.
- Upon completion, Coastal Countertops will remove all installation-related debris and return the area to a broom-clean condition.
- Your installers will conduct a final inspection with you. This is the best time to ask any questions and/or resolve any concerns.
- Seam placement is dependent on color, stability, site accessibility and size of material. A customer can request a specific seam location; however, final seam placement is at the discretion of Coastal Countertops.
- Do not touch the tops, seams, or sink for at least 24 hours so the silicone has time to fully cure.